

## HOW TO START YOUR WATCH

If your watch has a plastic guard, start your watch by removing the plastic guard from under the crown, then push the crown as far as it will go against the case to the "IN" position.

## REPLACING YOUR BATTERY

With normal wear, your new watch will run for a full year before it needs battery replacement.

When the movement no longer functions (check *case* that the crown is not extended in the time setting position), have the battery immediately replaced. Weak, dead batteries left in the watch for an extended time may damage the electronic movement. To change the battery your watch may be sent to our service center.

## FOLLOW THESE INSTRUCTIONS FOR PROMPT SERVICE

If your watch needs service, wrap it carefully in tissue paper or similar soft material and pack it in a mailing carton.

We advise you to send your watch insured mail. Do not send the gift box because it will not be returned to you.

Never include any special watchband or any other article of personal value in your shipment.

1. Do not return watch to store. Return for service to address below.
2. Pack carefully, but not in watch box. Boxes cannot be returned.
3. Fill in all the information and enclose this certificate in package with \$6.50 handling payment.
4. Print out address clearly on package, also your name and return address and mail insured to:

**ACCUTIME WATCH CORP. / SERVICE CENTER**  
**1001 AVENUE OF THE AMERICAS 6<sup>TH</sup> FL. NY, NY 10018**  
**LIMITED WARRANTY AND SERVICE INFORMATION**  
**, as defined by FTC regulations**

*Accutime Watch* warrants to the original consumer purchaser that the movement of your new watch will be free from original defects in workmanship and material for one year from the date of purchase. Your watch movement will be either replaced or repaired, or the watch will be replaced with one of an equal or greater value at our option, or timekeeping accuracy adjusted with out charge during the warranty period.

This warranty does not apply to the bracelet, case or crystal. The case, crystal and bracelet are sold "as is." The entire risk as to their quality and performance is on the buyer and should they prove defective, the buyer, not the manufacturer, distributor or retailer, assumes the entire cost of all necessary service or repair. The warranty does not extend to any parts of your new watch that have been subjected to misuse or accident. Nor does it cover any *Accutime Watch* that has been tampered with, altered or repaired other than by *Accutime Watch* service centers.

**ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PURPOSE ARE EXPRESSLY DISCLAIMED, COMMENCING ONE YEAR FROM DATE OF ORIGINAL PURCHASE.**

Some states do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**YOU WILL BE REQUIRED TO PROVIDE PROOF OF PURCHASE TO ESTABLISH THE FACT THAT YOUR WATCH IS WITHIN THE WARRANTY PERIOD.** During the warranty period there is no charge for the repair or replacement of your watch movement. However, there is a \$6.50 charge for handling. This handling charge may be changed without notice by *Accutime Watch Corp.* For repair or replacement of parts not covered by this warranty or after the warranty expires you will be notified of the cost of repairs. To obtain service, mail your watch via insured parcel post to:

DO NOT MIX OLD AND NEW BATTERIES  
DO NOT MIX ALKALINE, STANDARD, OR RECHARGEABLE BATTERIES  
DO NOT IMMERSE IN WATER  
DO NOT WEAR IF CASEBACK IS MISSING OR DISSASSEMBLED  
MADE IN CHINA

**ACCUTIME WATCH CORP. / SERVICE CENTER**  
**1001 AVENUE OF THE AMERICAS 6<sup>TH</sup> FL. NY, NY 10018**

Enclose a note telling why the watch needs repair. Remember to include a check or money order for \$6.50. Do not send Cash. A BILL OF SALE, CANCELLED CHECK OR PAYMENT RECORD SHOULD BE KEPT (AND COPY SUBMITTED WITH WARRANTY WORK) TO ESTABLISH THE WARRANTY PERIOD. Do not mail the original watch box because it cannot be returned. **PACK YOUR WATCH CAREFULLY AND SEND IT INSURED PARCEL POST SINCE ACCUTIME WATCH CANNOT BE RESPONSIBLE FOR WATCHES LOST OR DAMAGED IN TRANSIT. (PRINT CLEARLY)**

YOUR NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY & STATE \_\_\_\_\_

ZIP CODE \_\_\_\_\_

EMAIL \_\_\_\_\_



**ACCUTIME**  
WATCH CORPORATION

WM-1YW

## COMO PONER EN FUNCIONAMIENTO EL RELOJ

Si el reloj tiene una cubierta de plástico, se debe comenzar quitando la misma, que se encuentra por debajo de la corona, y luego se debe presionar la corona hacia la caja, hasta que se detenga en la posición "IN".

## COMO CAMBIAR LA PILA

Al usarse normalmente, su reloj Accutime funcionará durante un año completo antes de que sea necesario cambiarle la pila. Cuando el mecanismo ya no funciona (comprobar antes que la corona no esté extendida hacia afuera, en la posición utilizada para el ajuste de la hora), se deberá cambiar inmediatamente la pila. Si una pila debilitada o agotada se deja en el reloj durante un largo periodo, esto podría dañar el mecanismo electrónico. Para cambiar la pila se recomienda que se envíe el reloj a un centro de servicio especializado.

## PARA OBTENER SERVICIO RAPIDO, SIGA ESTAS INSTRUCCIONES

Si su reloj necesita servicio, envuélvalo cuidadosamente en papel de seda u algún otro material suave y colóquelo en una caja de cartón propia para envíos postales. Le aconsejamos asegurar su envío. No envíe el estuche en que recibió el reloj porque no podremos devolvérselo. Tampoco envíe brazaletes espaciales ni otros artículos de valor.

1. No lleve el reloj a la tienda donde lo compró. Envíelo a la dirección del Centro de Servicio que figura más abajo.
2. Empaquelo cuidadosamente, pero no en un 01 o 10, uche en un 10 recubuo. No podamos devolver los estuches.
3. Hartura en total la información y encierra este certificado en paquete con \$6.50 pago de la manipulación.
4. Escriba nuestra dirección, así como su propio nombre y dirección postal, claramente, en letra de imprenta, en el paquete y envíelo por correo asegurado a:

**ACCUTIME WATCH CORP. / SERVICE CENTER**  
**1001 AVENUE OF THE AMERICAS 6<sup>TH</sup> FL. NY, NY10018**  
**GARANTIA LIMITADA / INFORMACION DE REPARACION**  
**, como lo definen las regulaciones de la FTC (Comisión Federal de Comercio)**

Accutime Watch garantiza al comprador del consumidor original que el movimiento de su reloj nuevo será libre de defectos del original en habilidad y material por un año de la fecha de compra.

Su movimiento del reloj será o reemplazo o reposición, o se reemplazará el reloj con uno de igual o más gran valor a nuestra opción, o exactitud del timekeeping ajustó con fuera cargo durante el período de la garantía.

Esta garantía no se aplica a la pulsera, la caja o al cristal. La caja, el cristal y la pulsera se venden "tal como esté". Todo el riesgo en cuanto a su calidad y rendimiento recae en el comprador, y en caso de que se pruebe que están defectuosos, le corresponde al comprador, y no al fabricante, distribuidor o vendedor, el costo de todas las reparaciones o servicio que sean necesarios. La garantía no hace extendido a cualquiera partes de su reloj nuevo que se ha sujetado emplear malo accidente. Tampoco cubre ningún reloj ACCUTIME WATCH que haya sido manipulado, alterado o reparado por otro que no sean los centros de servicio Accutime Watch Corp.

TODAS LAS DEMAS GARANTIAS, EXPRESAS O IMPLICITAS, INCLUSIVE LAS GARANTIAS DE COMERCIALIZACION O MODIFICACION PARA UN PROPOSITO, SE RECHAZAN EXPRESAMENTE Y, EN CUANTO A LAS GARANTIAS IMPLICITAS, SE RECHAZAN EXPRESAMENTE POR UN AÑO DESDE LA FECHA ORIGINAL DE COMPRA.

Algunos estados no permiten limitaciones en la duración de las garantías implícitas, de modo que esta limitación puede no corresponderle a usted. Esta garantía le da derechos legales específicos y, usted puede tener también otros derechos que varían de estado a estado. SE LE REQUERIRA QUE PROPORCIONE LA PRUEBA DE LA COMPRA PARA ESTABLECER QUE EN EFECTO SU RELOJ SE ENCUENTRA DENTRO DEL PERIODO DE GARANTIA.

Durante el período de garantía la reparación o el reemplazo del movimiento de su reloj son gratis. Sin embargo, hay un cargo de 6.50 dólares por gestión Accutime Watch Corp. puede cambiar este cargo sin aviso previo. Se le notificará el costo de la reparación o el reemplazo de las piezas no cubiertas por esta garantía, o después que ésta haya caducado. Para obtener servicio, envíe el reloj en un paquete postal asegurado a:

NO MEZCLAR baterías viejas y nuevas

No mezcle pilas alcalinas, estándar o baterías recargables.

NO SUMERJA EN AGUA

No use SI FONDO DE CAJA DE FALTA O DISSASSEMBLED

HECHO EN CHINA

**ACCUTIME WATCH CORP. / SERVICE CENTER**  
**1001 AVENUE OF THE AMERICAS 6<sup>TH</sup> FL. NY, NY10018**

Ajunte una nota citando por qué el reloj necesita reparación. Acuerdese de incluir un cheque o giro postal por 6.50 dólares. No envíe dinero en efectivo. DEBE GUARDAR LA FACTURA DE VENTA, CHEQUE CANCELADO O REGISTRO DE LA VENTA (Y SOMETE UNA FOTOCOPIA CON EL TRABAJO BAJO GARANTIA) A FIN DE ESTABLECER EL PERIODO DE GARANTIA. No envíe por correo la caja original del reloj porque no se puede devolver. EMPAQUETE EL RELOJ CON CUIDADO Y ENVÍELO EN UN PAQUETE POSTAL ASEGURADO, YA QUE ACCUTIME WATCH CORP. NO PUEDE SER RESPONSABLE POR RELOJES PERDIDOS O DAÑADOS EN TRANSITO.  
(LETRA DE IMPENTA CLARA)






SU NOMBRE \_\_\_\_\_

DIRECCIÓN \_\_\_\_\_

CIUDAD VESTADO \_\_\_\_\_

CODIGO POSTAL \_\_\_\_\_

EMAIL \_\_\_\_\_



## OPERATING INSTRUCTIONS

10:08

6 30

:40

**Normal Time Display:** Press button B2 until the display shows the hour, minutes, and colon blinking

**Date Display:** Press button B1 once to show the month and date digits. Note, the display will return to the normal time display after 2- 3 seconds.

**Seconds Display:** Press button B1 twice to show the second digits. To return to the normal time display, press button B1 once.

**Alternating Time and Calendar Display:** Press button B2 once, and the display will automatically alternate between the normal time display and the date display. To return to the normal time display, press button B2 five times.

## SETTING THE TIME AND CALENDAR

**Setting the Month:** Press button B2 twice. The display will show the month digits on the left. Press button B1 repeatedly to advance the month digits. Rapid advance may be used by holding in button B1.

**Setting the Date:** Press button B2 once. The display will show the date digits on the right. Press button B1 repeatedly to advance the date digits. Rapid advance may be used.

**Setting the Hours:** Press button B2 once. The display will show the hour digits, a colon and an "A" or "P" (am/pm) symbol. Press button B1 repeatedly to advance the hour digits. Rapid advance may be used.

**Setting the Minutes:** Press button B2 once. The display will show the minute digits and a colon. Press button B1 repeatedly to advance the minute digits. Rapid advance may be used.

**Completion:** To return to the normal time display. Press button B2 once. (If colon is not blinking, press button B1 once.)

DO NOT IMMERSE IN WATER.

DO NOT WEAR IF CASEBACK IS MISSING OR DISASSEMBLED.

DO NOT MIX NEW AND OLD BATTERIES.

MADE IN CHINA.

